

# BEAM Install Guide

---

## Height Requirements

Discuss and confirm placement of the BEAM system with the customer's authorized point of contact.

System Height	Minimum Size		Maximum Size	
	Width	Height	Width	Height
9'	7'	5' 6"	8' 4"	6' 4"
10'	7' 9"	6'	9' 2"	6' 10"
11'	8' 9"	6' 7"	10'	7' 6"
12'	9' 6"	7' 1"	10' 10"	8' 3"
13'	10' 4"	7' 9"	11' 9"	8' 11"
14'	11'	8' 3"	12' 7"	9' 6"

## Image Orientation



This shows a bird's eye view of unit's display on the floor; this shows that the display is rectangle and the length runs parallel to the BEAM logo.